



19 Midlands Mills, Cross Hills, North Yorkshire BD20 7DT

Tel: (01535) 630776

Fax: (01535) 630827

sales@uklabchairs.co.uk

www.uklabchairs.co.uk

Operating & Maintenance

All Framework including bases

Clean with a damp soapy cloth and rinse well with clean water.

A soft brush can be used for heavy soiling.

PU seats and backs

Clean with a damp soapy cloth and rinse well with clean water.

A soft brush can be used for heavy soiling.

PU can also be bleach cleaned if required but we recommended that a damp soapy cloth be used after and they are rinsed well with clean water.

For ESD Chairs in Camira Hi Tech

Vacuum regularly. Professionally dry clean or wipe clean with a damp cloth.

For upholstery in Just Colour Vinyl

Clean with a damp soapy cloth and rinse well with clean water

A soft brush can be used for heavy soiling

In Cases where disinfecting is required the vinyl surface can be cleaned with a solution of disinfectant specified by manufacturers.

Wipe clean regularly with a damp cloth to remove dust particles and light soiling.

Remove spillages promptly (within 15 minutes) with an absorbent dry cloth.

For heavy soiling use a soft brush and tepid soapy water (non alkaline) Rinse clean

With clear water, dry with an absorbent cloth.

Extreme soiling/infection control use 5% sodium hypochlorite (bleach) solution

Do not machine wash or dry clean.

Do not use polish, solvents or stain remover.